Excavators - Controls Instructions

The operator must read these instructions before starting the excavator.